

WINDOWS 7 QUICK INSTALL GUIDE - INPORT DELUXE

Plugging in your INport:

Find a free USB port on the back of your computer and plug in the supplied USB cable. Plug your INport into the other end of the USB cable. Don't plug your INport into a USB hub. Windows 7 will automatically load the necessary drivers.

For Windows 7 running Aero, go to:

START > CONTROL PANEL > HARDWARE AND SOUND

under SOUND: click on MANAGE AUDIO DEVICES

under the RECORDING tab:

- right click on **Microphone INport** and select **Disable**
- right click on **Line INport** and select **Enable**
- right click on **Line INport** and select **Set as Default Device**. This option will not be available if INport is already set as the default device. There will be a green tick icon next to **Line INport** if it is set as the default device.

under the PLAYBACK tab:

- right click on **Speakers INport** and select **Disable**.

For Windows 7 running Classic, go to:

START > CONTROL PANEL > SOUND

under the RECORDING tab:

- right click on **Microphone INport** and select **Disable**
- right click on **Line INport** and select **Enable**
- right click on **Line INport** and select **Set as Default Device**. This option will not be available if INport is already set as the default device. There will be a green tick icon next to **Line INport** if it is set as the default device.

under the PLAYBACK tab:

- right click on **Speakers INport** and select **Disable**.

Recording from your Stereo:

For everything else related to installing the software and recording, Windows 7 operates exactly the same as Windows Vista. Please follow the Windows Vista instructions that start on page 8 of the Xitel INport Deluxe User Manual.